


# FEISOL



## CB-30C

### Including a QP-144750 Quick Release Plate

#### Instructions:

To insert the quick release plate: First, loosen the (3) Quick release knob. Press the (1) safety button to insert the quick release plate. Ensure the plate is securely locked in place by rocking the plate back and forth on the plate base. Then tighten the (3) Quick release knob.

To release the quick release plate: First, loosen the (3) Quick release knob then press (1) safety button inward to release the quick release plate.

(4) Ball locking knob: By turning the knob, one can easily adjust the position of the ball. (5) Friction control knob can control the amount of the friction applied to the ball. First loosen the ball locking knob to the degree one desires then tighten the friction control knob lightly. Then every time you release the ball locking knob, the friction of the ball will be set to the pre-set degree. Friction control knob only needs to be adjusted once, and do not turn it more than half turn.

	<b>HEAD HEIGHT</b>	7.5cm / 2.95 inches
	<b>WEIGHT</b>	283g/0.62lbs
	<b>BALL DIAMETER</b>	30mm / 1.18inches
	<b>MAX LOAD</b>	8Kg / 17 lbs
	<b>THREAD SIZE</b>	3/8" Including 1/4"~3/8" screw

## QUICK RELEASE PLATE

QP-144750



QP-1447100

